



1 Using the Soft Fan with EL-103 Sea Spray, apply 3 coats to the inside of ceramic. Apply 2 coats to the outside. Allow glaze to dry between coats.

2 Pour around 1 TBS of PC-602 White Cascade onto the palette. Dip a soft round brush into the glaze and randomly "glob" the glaze going around the middle of the ceramic (on outside only). Allow glaze to dry.



3 Using the Soft Fan with EL-208 Moss Creek, apply 2 coats to the outside of the bowl. Recede the final coat to prevent dripping. Allow glaze to dry between coats.



4 Pour around 1 TBS of PC-601 Clear Cascade onto the palette. Dip the Soft Fan into the glaze and randomly "glob" the glaze going around the rim of the ceramic (on the outside only).



*finished result!*