

Color Me Mine® TO-GO KIT

PAINT INSTRUCTIONS

1. Before you begin, prepare your workspace. Things you will need are water bowl, paper towels, and a paint pallet (paper plate).
2. Wipe down bisque with a damp sponge to remove ceramic dust.
3. Plan out your design. You can lightly mark bisque surface with a pen. It will burn off in the firing process.
4. Start with your lightest color first. One coat of any color will be translucent: Two coats will be semi-opaque and show brush strokes. Three coats will be opaque. Always let one coat dry before applying the next coat. Make sure to rinse your brush with clean water between colors.
5. Once finished painting, allow the pieces to dry for 24 hours before wrapping them up and transporting them to be glazed and fired. We will dip in a clear glaze before firing so that any parts of the piece unpainted will be white, shiny, and food-safe.



TIPS & TRICKS

If you make a mistake and wish to remove some paint from your piece, there are two options:

1. Use a damp sponge and wipe the paint off the piece before it dries.
2. Wait for the paint to dry and then gently scrape it off the surface using a piece of sandpaper.

Only use provided ceramic underglazes to paint with. Do not use glitter, acrylics, markers, or any other materials on the pottery.